

How to Paint a Front Door

with Purdy®

Before you start: **Gather supplies.**

- 2" or 2.5" Nylox™ Brush
- Parrot™ 4.5" x 1/4" Jumbo Mini Roller Covers
- 12" Jumbo Mini Roller Frame
- Premium 10-in-1 Multi-Tool
- Mini paint tray
- Paint
- Putty
- Sandpaper
- Tape
- Drop cloth
- Screwdriver
- Rag



STEP 1: Prep the door.

Remove all hardware. Clean the door thoroughly.

Then, use a premium 10-in-1 multi-tool to fill any dents and fix other imperfections with putty. Let the putty fully dry. Lightly sand the surface to ensure a smooth final result. Thoroughly wipe the surface with a lint-free cloth to remove any dust.

STEP 2: Tape.

Tape off any windows and the surrounding trim. Place a drop cloth on the ground.

STEP 3: Plan your route & paint.

To maximize efficiency, use the diagram to guide the order in which you paint.

Use your Nylox™ brush to cut in and around windows and recess areas.

Nylox brushes are super soft and create a perfect finish with no brush marks.

Use your Parrot™ mini roller to paint the flat areas of the door. Parrot's quality mohair fabric is ideal for creating a smooth, mirror-like finish.

» Helpful tips: Depending on the formula and the color you are using, you might need to apply multiple coats. Always follow paint manufacturer's label instructions for recoat and dry times.

Avoid shutting the door until the paint is fully cured to prevent it from sticking to the frame.

Once the paint is fully cured, peel off the tape and reattach the hardware.

